

Spot Free DI Rinsing Systems 78300 & 78400



Your system has been shipped partially disassembled to prevent damage to delicate components during the shipping process. An adjustable wrench is all that is required.

Your Spot Free DI system includes the following components:

- 2 DI cartridges (installed)
- 2 Big Blue Housings #10 or #20
- HD Mounting Bracket
- Dual Line TDS Meter
- 2 Brass Tees with fittings
- 5' Connection Hose



The brass Tees are universal (can fit either side) and are to be inserted and tightened in the incoming and outgoing ports of the DI system. Hand tighten at first being careful not cross thread. Using an adjustable wrench tighten one full turn.



Depending on the supplied TDS Meter you will either slide the TDS meter into the mounting bracket or peel the backing off the tape directly affixed to the meter and adhere it to the front and center of the bracket. DO NOT touch the tips of the 2 probes on the meter as oils and contaminants from your hands can damage and affect the performance of the probes.



The probes are marked IN and OUT. Insert the IN probe on the incoming side of the system (left) and the OUT on the outgoing side. If you need to remove the probe, press down on the grey collar on the fitting.